


No. and Component

- 1 <Custom 1> (Copy) button
- 2 <Custom 2> button
- 3 <Custom 3> (Review) button
- 4 <Log In/Out> button
- 5 <Clear All> button
- 6 <Power Saver> button
- 7 <Interrupt> button
- 8 <Stop> button
- 9 <Start> button
- 10 Numeric Keypad
- 11 <Speed Dial> button
- 12 <C (Clear)> button
- 13 <Dial Pause> button
- 14 <Machine Status> button
- 15 <Job Status> button
- 16 <Service Home> button

Copy




At [Copy] menu, select copy features. Press <Start> button.




At [Simple Copy] menu, select the basic copy features. Press <Start> button.

Specifying Finishing Options




Select [Copy Output].




Staple: The number of sheets that can be stapled is 2 – 100 (when 80 gsm paper is used).
Hole Punch: 2 holes or 4 holes is available for selection.

Email




Select a recipient from the [Address Book]. Press <Start> button to Scan.
 OR Check [Preview] before pressing <Start> (Document pages can be viewed before sending out)
 For detailed setting, go to below:




A: Preview (scanned pages)
 B: Change Settings (additional page)
 C: Select [Send (Last Original)] to send out.

Scan to PC



Select a recipient from the [Address Book]. Press <Start> button to Scan.
 OR Check [Preview] before pressing <Start> (Document pages can be viewed before sending out)
 For detailed setting, go to below:



A: Preview (scanned pages)
 B: Change Settings (additional page)
 C: Select [Send (Last Original)] to send out.